불ADD-ON OPTIONS

AIR CONDITIONING SYSTEM: Compressor, clutch assembly and pulley, evaporator, receiver dryer. (excluding seals & gaskets unless the option has been purchased).*

FUEL AND INJECTION SYSTEM: Fuel pump, fuel injection and distribution pump, fuel injectors and fuel pressure regulators.*

HEAD GASKET(S): Cylinder head gasket(s).*

HI-TECH POWER EQUIPMENT: Electronic engine management sensors (Cam, Crank, O2), transmission computer control module, anti-lock brake/traction system (control module, exciter rings, pump and pressure modulator assembly), electronic temperature control module, electronic ignition computer control modules, fuel injection computer control modules, digital dash instrumentation (speedometer, tachometer, odometer, fuel, oil, temperature and voltage displays only).*

POWER ACCESSORIES: Power window motors, power regulators, power door lock actuator motors and switches, power seat motors, power antenna, electronic trunk release actuators, exterior mirror motors, sunroof motor and convertible top motors. Power sliding door and lift gate motors, headlamp wiper motors.*

POWERTRAIN PLUS PACKAGE: Water pump, starter motor and solenoid, alternator and voltage regulator, CV Joints, CV axle shafts.*

RENTAL CAR ALLOWANCE: In the event of a breakdown or failure of a covered part under this contract we will reimburse you for a rental car to a maximum of \$35 (thirty five) CDN per each 8 hours of repair time according to the Mitchell labor guide.*

SEALS & GASKET(S): All seals & gaskets used to obtain fluids & lubricants within the covered parts including Cylinder Head Gasket(s), intake and exhaust manifold gasket(s).*

SUPPLEMENTARY PARTS:

ENGINE PARTS: Water pump, motor mounts & torque struts, oil pan, harmonic balancer and pulley, intake and exhaust manifolds, timing chain(s) or belt and their gears and tensioners, dipstick and tube, oil pressure sending unit and temperature gauge sending unit.*

DRIVELINE: CV Axle shafts, CV joints and boots, main drive shaft, universal joints, hanger bearings.*

TRANSMISSION / TRANSAXLE: Flexplate, flywheel, ring gears, mounts.*

TRANSFER CASE: Transfer case mounts.*

TRANSFER CASE (4X4 / AWD): All internally lubricated parts including; case, gears and sprockets, chain. (excluding seals and gaskets).*

TURBO & SUPERCHARGER: Housing, waste gate controller, intercooler, hard lines, compressor, clutch and pulley, by-pass valve and ducting. (excluding seals and gaskets).*

UNLIMITED KILOMETERS: No mileage restriction for the total term of the contract.*

ZERO DEDUCTIBLE: In the event of a breakdown of a covered part the deductible will be reduced to \$0 (Zero) CDN on each and every claim.*



UNLIMITED NUMBER

OF CLAIMS*

NATIONWIDE COVERAGE CANADA & U.S.*

DIRECT PAYMENT

TO AUTHORIZED SERVICE CENTRES*

GUARANTEED APPROVAL

ON ALL ELIGIBLE CLAIMS*

NO CLAIM DOUBLE YOUR TERM OPTION*

*ASK YOUR DEALER

For complete coverage details, please see our terms and conditions.

EASY FINANCING

COVERAGE CAN BE INCLUDED IN YOUR VEHICLE LOAN.

SECURE COVERAGE PLANS
For your protection and "peace of mind"

Tel.: 1-888-666-8579 Fax: 1-888-666-8537

Mailing Address: P.O. Box 487 Victoria Station Montreal, QC, H3Z 2Y6



autogard.ca™

* This is not a contract and the contents of this brochure are limited by its size.

All benefits described are subject to the terms and conditions of the contract and they are subject to change at anytime without notice. HST must be added to the premium.

Effective May 1st, 2016. V01-050116





ECONOMY PLANS COVERAGE



EXTENDED AUTOMOBILE WARRANTY

YOUR CAR. OUR COVERAGE.



1-888-666-8579 | autogard.ca™

BASIC 600

COVERAGE:

ANY YEAR, MAKE & MODEL WITH ANY MILEAGE **MAXIMUM LIABILITY PER CLAIM \$600 (CDN)**

BASIC POWERTRAIN 600

ENGINE: Engine Block and cylinder head(s), all internally lubricated mechanical parts including: crankshaft, main bearings, crankshaft gears, push rods, pistons, piston rings and pins, intake and exhaust valves, valve springs and retainers, valve covers, valve guides, lifters, rocker arms, shafts and pivots, timing chain or belt, oil pump and shaft. (excluding Seals and gaskets).*

TRANSMISSION: AUTOMATIC: Housing (when damaged from within), torque converter, valve body, gear sets, main and intermediate shafts, vacuum modulator, oil pump & governor, friction and steel plates, clutches and bands. (excluding all manual clutch components, external linkages, flexplates and flywheel. Seals and gaskets are also excluded).*

MANUAL / STANDARD: Housing (when damaged from within), main and intermediate shafts, gear sets, synchronizer rings, shaft fork. (excluding flexplates, flywheel, ring gears and external linkages. Manual clutch components, bearings, pressure plate. Seals and gaskets are also excluded).*

DIFFERENTIAL: Front and/or rear differential housing (when damaged from within), all internally lubricated mechanical parts including: main shaft, crown and pinion gears, carrier gear and housing. (excluding Seals & gaskets, 4WD locking hubs).*

ROADSIDE ASSISTANCE ALLOWANCE: We will reimburse you up to \$60 (sixty) Canadian dollars per occurrence, if the breakdown is covered under your contract.*

TOWING ALLOWANCE: We will reimburse you for towing charges of up to \$60 (sixty) Canadian dollars per occurrence if the breakdown is covered under your contract.*

TRAVEL & HOTEL ALLOWANCE: We will reimburse you to a maximum of up to \$150 (one hundred and fifty) Canadian dollars per claim, if the breakdown is covered under your contract.*

BASIC 800



COVERAGE:

ANY YEAR, MAKE & MODEL WITH ANY MILEAGE **MAXIMUM LIABILITY PER CLAIM \$800 (CDN)**

BASIC POWERTRAIN 800

ENGINE: Engine Block and cylinder head(s), all internally lubricated mechanical parts including: crankshaft, main bearings, crankshaft gears, push rods, pistons, piston rings and pins, intake and exhaust valves, valve springs and retainers, valve covers, valve guides, lifters, rocker arms, shafts and pivots, timing chain or belt, oil pump and shaft. (excluding Seals and gaskets).*

TRANSMISSION: AUTOMATIC: Housing (when damaged from within), torque converter, valve body, gear sets, main and intermediate shafts, vacuum modulator, oil pump & governor, friction and steel plates, clutches and bands. (excluding all manual clutch components, external linkages, flexplates and flywheel. Seals and gaskets are also excluded).*

MANUAL / STANDARD: Housing (when damaged from within), main and intermediate shafts, gear sets, synchronizer rings, shaft fork. (excluding flexplates, flywheel, ring gears and external linkages. Manual clutch components, bearings, pressure plate. Seals and gaskets are also excluded).*

DIFFERENTIAL: Front and/or rear differential housing (when damaged from within), all internally lubricated mechanical parts including: main shaft, crown and pinion gears, carrier gear and housing. (excluding Seals & gaskets, 4WD locking hubs).*

ROADSIDE ASSISTANCE ALLOWANCE: We will reimburse you up to \$60 (sixty) Canadian dollars per occurrence, if the breakdown is covered under your contract.*

TOWING ALLOWANCE: We will reimburse you for towing charges of up to \$60 (sixty) Canadian dollars per occurrence if the breakdown is covered under your contract.*

TRAVEL & HOTEL ALLOWANCE: We will reimburse you to a maximum of up to \$150 (one hundred and fifty) Canadian dollars per claim, if the breakdown is covered under your contract.*

BASIC 1000

COVERAGE:

ANY YEAR, MAKE & MODEL WITH ANY MILEAGE MAXIMUM LIABILITY PER CLAIM \$1000, \$1500, \$2000 TO \$3000 (CDN)

BASIC POWERTRAIN 1000

ENGINE: Engine Block and cylinder head(s), all internally lubricated mechanical parts including: crankshaft, main bearings, crankshaft gears, push rods, pistons, piston rings and pins, intake and exhaust valves, valve springs and retainers, valve covers, valve guides, lifters, rocker arms, shafts and pivots, timing chain or belt, oil pump and shaft. (excluding Seals and gaskets).*

TRANSMISSION: AUTOMATIC: Housing (when damaged from within), torque converter, valve body, gear sets, main and intermediate shafts, vacuum modulator, oil pump & governor, friction and steel plates, clutches and bands. (excluding all manual clutch components, external linkages, flexplates and flywheel. Seals and gaskets are also excluded).*

MANUAL / STANDARD: Housing (when damaged from within), main and intermediate shafts, gear sets, synchronizer rings, shaft fork. (excluding flexplates, flywheel, ring gears and external linkages. Manual clutch components, bearings, pressure plate. Seals and gaskets are also excluded).*

DIFFERENTIAL: Front and/or rear differential housing (when damaged from within), all internally lubricated mechanical parts including: main shaft, crown and pinion gears, carrier gear and housing. (excluding Seals & gaskets, 4WD locking hubs).*

ROADSIDE ASSISTANCE ALLOWANCE: We will reimburse you up to \$60 (sixty) Canadian dollars per occurrence, if the breakdown is covered under your contract.*

TOWING ALLOWANCE: We will reimburse you for towing charges of up to \$60 (sixty) Canadian dollars per occurrence if the breakdown is covered under your contract.*

TRAVEL & HOTEL ALLOWANCE: We will reimburse you to a maximum of up to \$150 (one hundred and fifty) Canadian dollars per claim, if the breakdown is covered under your contract.*

advantage